#### Applying serial number instrucstion

- 1. Check front below of product or back below part of package for serial number,
- 2. Scan the QR code displayed on the bottom in this page in order to contact. "Customer Service Center for Magmo".
- 3. Then submit the serial number to "Customer Service Center for Magmo" page.











# Guarantee

This product has been manufactured and imported after thorough quality control and inspection. The quality is quarenteed with the contents listed below Product

Product Name	Buzz Magmo Call Recorder	Mode <b>l</b> Number	BUZZ-V7
Date of Purchase		Warranty	6 months from the date of purchase
Customer		Seller	

#### Product Detail

Product Name	Buzz Magmo Call Recorder
Model Number	BUZZ-V7
Memory	32GB (500 Hours recording)
Continuous recording time	6 hours maximum
Battery usage time	6 hours per full charge
Battery charging time	90 minutes
Product size	64.00mm × 95.80mm × 6.80mm
Product weight	44.2g (1.56oz)
Battery	3,7 v Lithium-polymer 280mAh
environment	Humidity: 20~40%

#### 使用注意事項

#### 潘钰錄音

- 根據使用者的所在地區, 若無事先微得雙方常事人同意,
- 在只微得一方同意的情况下進行涌跃錄音時,可能會受到法律制裁。
- 本公司對此的處罰或損失將不承擔責任。
- 本產品是磁吸贴附在 iPhone 上使用的產品.
- 未根據指示之方法使用而造成的損失,本公司恕不負責.

#### 其他錄音

- 將本產品用於竊聽第三方對話的目的而獲利時,可能會受到法律制裁。
- 本公司對此的處罰或損失概不負責.
- 在非為對話的其他情況下、發放錄音的著作(演出、講座等)時,根據著作權法可能會受到處罰。 本公司對此概不負責

- 如果您是收到產品後第一次使用 結在使用前將產品充滿雷約 1 小時
- 將錄製的文件從產品傳到電腦時,請使用包裝中隨附的 USB 充電線.
- 如果使用不同的 USB 充雷線, 可能無法進行傳輸,
- 要開始發製、請將按鈕"往上推"、在通話期間的任何時候。 您都可以連接產品並將按鈕"往上推"以輕鬆開始錄音。
- 要結束錄製和充電,請將按鈕"往下推"滑動,只有當按鈕"往下推"結束錄製時。 才能對產品推行充雷

## Product Composition



(Lightning to USB-A type)





③ 使用說明書

# 產品各部位名稱







## 使用方法

#### 1. 開始與結束錄音



MagSafe 磁石處上

請將產品正面貼於手機背面



(底部的狀態指示 LFD





### 银音內容將儲存後並 偿每 0.5 秒閃爍--次転慢) 結束袋製 若不無袋製 請將發音卻開闊維 持在下方即可。



- 請另行先將 MagSafe 磁石貼紙貼於手機背面,再貼上本產品. ※ 若未將本產品貼於手機上,可能會導致錄製的聲音品質不佳。
- ▲ 連續錄音最長可達6小時。
- 心 為防止產品持續耗電,在不使用的情況下,請關閉錄音鈕(往下推)。

#### 2. 確認錄音檔案

- 請使用隨附的 USB 傳輸線連接至電腦.
- 與電腦準接時無法同時進行錄製。
- 連接電腦時會被識別為「行動硬碟」,可播放、複製及刪除錄音文件。 ▲ 錄音檔 (MP3) 的文件名按錄製順序保存.
- ③ 請務必先執行「安全移除硬碟」後,再將本產品從電腦拔除.

#### 3. 充電(充電所需時間:約90分鐘)

- ① 將錄音鈕往下推, 使用 USB 傳輸線連接充電孔.
- 錄製中無法同時充電. 請務必先關閉錄製後再進行充電。
- ② 開始充電時,產品底部 LED 狀態指示燈將會顯示紅色。 充電時無法同時進行錄製。
- ③ 產品完充時,底部 LED 狀態指示燈會顯示綠色。

#### 4. 雷池狀態顯示

- 可以通過錄製完成時亮起的狀態指示燈的顏色來檢查電池狀態。
- ⚠ 錄製過程中 LED 狀態指示燈將不會京。
- ※公: 錄製結束時,根據剩餘電池電量,會有3種狀態。

狀態指示燈	紅色	藍色	綠色
剩餘電量	(不足) 0~30%	(普通) 30~70%	(充足) 70~100%

#### 5. 初始化設定

- 連接到電腦後,執行「格式化硬碟」將會刪除產品上儲存的所有數據.
- 錄音檔一旦刪除,數據將無法恢復.

#### 使用注意事項

- 請勿將本產品長時間放置在加熱設備附近、陽光直射處、多灰應或會振動或潮濕的地方。 請勿隨意處置本產品或使本產品受到衝擊。
- 請放在兒童接觸不到的地方。
- 小心不要將產品泡水或大量接觸水分。
- 如果產品有問題, 請停止使用產品,及時洽詢客服。
- 如果記憶卡已滿, 錄音不會進行額外錄音紀錄
- 請提前將重要音檔保存在電腦裡或單獨保存在記錄卡上。
- 對於因濫用本產品或其他人為因素而造成的任何記錄內容丟失. 製造商棚不負責.

#### 客服事項

- 請於此連結 https://bit.lv/3z3ZDN1 提出產品客服相關諮詢。
- 請掃描右側 QR Code、開啟「Magmo 線上客服中心」.
- 自購買之日起6個月內、對產品的故障和製造上的缺陷免費提供更換服務。
- 心 以下情況時客服為付費服務:因人為使用中處理不恒導致的故障。 或為人為任意修改而導致的故障、或因火災、洪水、 地震等自然災害而導致的故障。
- 依據本公司規定 雲有產品下面下方或句裝背面標示之 「産品序號」、才能獲得完整的客戶支援服務。 請掃描 OR Code 開啟「Magmo線上客服中心」。
- 並登錄產品正面下方或包裝背面標示之「產品序號」。



## 登入序號資料

請按照以下說明註冊您的序號、提供6個月保固以及免費維修。

#### 序號資料登入方法

- 1.請留意產品正面下方或包裝背面標示之「產品序號」。
- 2. 掃描下方 OR Code。開啟「Magmo 線上客服中心」。
- 3 晉錄產品序號









#### 產品保固書

# 品質保證書

#### 本產品為經完善的品質管理及檢驗後製造進口的產品 將依以下所述明之內容執行產品品質保證

<b>全品名稱</b>	Buzz Magmo Call Recorder	地址	BUZZ-V7
購入日		保固期	自購買日起6個月內
顧客名		購買店家	

#### 產品規格

品名	Buzz Magmo Call Recorder
型號	BUZZ-V7
記憶體容量	32GB (500小時錄音)
最大連續錄音時間	6時間
電池使用時間	1次最多 6 小時的錄音 (電量為全滿時)
電池所需充電時間	90分鐘
大小	64.00mm × 95.80mm × 6.80mm
重量	44.2g (1.56oz)
電池	3.7 v Lithium-polymer 280mAh
使用環境溫度	温度:0~40°C, 温度:20~40%

#### 限用物質含有情況標示聲明書

設備名稱 : BUZZ Equipment name	及備名稱: BUZZ Magmo Call Recorder,型號(型式): BUZZ-V7 quipment name Type designabon(Type)					
	限用物質及其化學符號					
單元Unit	鉛 Lead (Pb)	录 Mercury (Hg)	鎬 Cadmium (Cd)	六價絡 Hexavolent chromium (Cr+6)	多溴聯苯 Polybrominated triphenyts (PBB)	多溴二苯醚 Polytrominated dipheryl ethers (PBDE)
電路板		0	0	0	0	0
線材	0	0	0	0	0	0
內部配線	0	0	0	0	0	0
MERN		0				0

- 備表1. "超出0.1 wt %"及"超出0.01 wt %"係指得用物質之百分比含量超出百分比含量基準值。
- Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.
- 備老2 \*○" 係指該項限用物質之百分比含量未超出百分比含量基準值
- Note 2: "O" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.
- 備表3 "一" 係指該頂限用物質為抹除頂目
- Note 3: The "-" indicates that the restricted substance corresponds to the exemption.



#### 제품 사용 시 주의사항

#### 통화 음성 녹취 관련

- 사용자의 거주지역에 따라 양 당사자 모두의 동의를 구하지 않고 한 쪽의 동의만 구한 채로 토하 노음이 지해된 내 번전이 제대를 받을 스 있으며 보나는 이에 따로 워벅 호우 소해에 대하여 책임을 지지 않습니다.
- 본 기기는 아이폰에 부착하여 사용하는 제품입니다. 본 제품의 사용 방법에 의거한 사용과. 관련된 지침을 따르지 않아 발생한 손해에 대해 책임지지 않습니다.

#### 기타 음성 녹취 관련

- 본 제품을 제3자의 대화를 도청하는 목적으로 사용하여 이득을 취할 시 법적인 제재를 받을 수 있으며, 본사는 이에 따른 처벌 혹은 손해에 대하여 책임을 지지 않습니다.
- 대화가 아닌 기타 경우에 녹취된 저작물(공연, 강의 등)을 배포할 지 저작권법에 근거하여. 처벌을 받을 수 있으며, 본사는 이에 대하여 책임을 지지 않습니다.

#### 사용 유의사항

- 제품을 송부 받고 처음 사용하시는 경우, 1시간 가량 충분히 충전하고 사용해주세요.
- 녹음 파일을 제품에서 PC로 옮기실 경우, 패키지에 동봉된 USB 케이블을 사용해주세요. 다른 USB 케이블을 사용하실 경우, 데이터가 옮겨지지 않는 경우가 있습니다.
- 높음을 시작하기 위해서는 "대각선 위로" 올려주세요. 통하 중 언제든지 제품을 부착하시면 "대각선 위로" 올려서 손쉽게 녹음을 시작하실 수 있습니다.
- 녹음을 종료하고 충전하기 위해서는 "대각선 아래로" 내려주세요. 버튼이 "대각선 아래로" 내려가 녹음이 종료된 상태여야만 제품 충전이 가능합니다.

## 제품 구성 본체



② USB 케이블 (Lightning to USB-A type) 



축전단자.

③ 매뉴얼

#### 제품 각 부분의 명칭







#### 제품 사용 방법

#### 1. 녹음 시작 및 종료







② 통하 높은 시작 된면이 버트읔 [내간선 의로 [페품 하단이 상태표시들에 파라색 LED가 0.5초간 1히 정등된니다)



③통하 높은 종류 제품 뒷면이 높음버트음 옥기면 높음이 되작된 IFF 대각선 아래로 내리면 높음 높음을 하시지 않을 때에는 제품 뒷면의 버튼을 대각선 아래로 내린 채로 유지합니다.

- ▲ 백세이프가 내장되어 있는 아이폰이 아닌 해도폰 기존에서 제품을 사용하실 경우 별도의 맥세이프 자석 스티커를 핸드폰 후면에 붙이신 후 제품을 핸드폰 후면에 부착하셔야 합니다.
- 제품을 핸드폰에 부착하지 않고 녹음 시 통화녹음품질이 떨어질 수 있습니다.
- 최대 연속 녹음 시간은 6 시간입니다.
- ☼ 제품 방전 방지를 위해 사용하시지 않을 때에는 버튼을 내려주세요.

#### 2. 녹음파일 확인

- ① 동봉된 USB 케이블을 사용하여 제품을 PC에 연결합니다.
- ⚠ 제품이 PC와 연결된 상태에서는 녹음이 불가합니다.
- ② 연결된 제품은 '이동식 디스크'로 인식되며, 음성파일의 재생, 복사, 삭제가 가능합니다. ▲ 녹음 파일(MP3)의 파일명은 녹음 순으로 기록되어 저장됩니다.
- ③ 제품을 PC에서 분리 시, 반드시 '하드웨어 안전하게 제거'를 실행하신 후 제품을 분리해주세요.

#### 축전 (축전 소요시간 : 약 90분)

- ① 제품 버튼을 대각선 아래로 내린 뒤 USB 케이블로 제품을 충전단자에 연결합니다. ▲ 녹음 중에는 제품을 충전할 수 없습니다. 꼭 버튼을 내리고 충전 해주세요.
- ② 충전이 시작되면 제품 하단에 빨간색 LED가 점등됩니다
- 충전 중에는 녹음 기능을 사용하실 수 없습니다.
- ③ 충전이 완료되면 제품 하단에 초록색 LED가 점등됩니다 ♠ 충전 환경에 따라 빨간색, 초록색 LED가 번갈아 점등될 수 있으나, 완충된 상태입니다.



# 5. 제품 초기화 내용이 저장된 후 종료됩니다.

#### PC에 연결한 상태에서 이동식 디스크를 포맷하면 제품이 모든 데이터가 삭제됩니다. ▲ 하번 삭제된 데이터는 본구가 불가능합니다.

☆ 제품 방전 방지를 위해 사용하시지 않을 때에는 버튼을 내려주세요.

#### 사용상의 주의

4. 배터리 상태 표시

상태 표시등

- 본 제품을 난방 기구 가까이나 직사광선이 닿는 장소, 먼지나 진동이 심한 장소, 습한 장소에 장치간 방치하지 마신치오.

배터리 상태는 녹음이 종료될 때 점등되는 상태 표시등의 색깔로 확인하실 수 있습니다.

배터리 잔량 (부족) 0~30% (보통) 30~70% (충분) 70~100%

- 본 제품을 일이로 분해하게 F제품에 충격을 가하지 마십시오.
- 어린이 손에 닿지않게 보관해주세요.
- 페풀이 친수되지 않도록 주의해 주십시오

최대 연속 녹음 시간은 6 시간입니다.

- 페풀에 문제가 있을 경우, 중지하시고 A/S록 받으시길 바랍니다
- 용량이 다 차면 추가로 녹음되지 않습니다. 중요한 내용은 PC, 또는 별도의 기록 매체에 미리 보관하여 주십시오.
- 본 제품의 오사용, A/S, 기타의 사유로 녹음 내용의 손실은 당사에서 책임지지 않습니다.

- A/S에 대한 문의는 카카오톡 채널 "BUZZ 고객센터" 로 문의해주세요.
- 오른쪽 상단 QR 코드를 스캔하시면 카카오톡 채널 "BUZZ 고객센터"로 연결됩니다.
- 구입일로부터 6개월 이내, 제품의 기능 이상 및 제조상의 결함에
- 대해 교체 서비스를 무상으로 제공합니다.
- ▲ 요상 서비스 · 사용상이 취급 보조이로 인한 고장 · 사용자이 임이이 내부 개조로 인하 고장 하대. 수해. 지진 등이 천대 변으로 인한 고장, 제품 보증기간이 지난 제품일 경우
- 제품 박스 후면에 부착된 관벨의 시간일 번호를 입력하셔야 당사 규정에 의한 서비스 지원을 받으실 수 있습니다. 서비스를 위해 제품 박스에 부착된 시리얼 번호를 오른쪽 QR 코드(BUZZ 고객센터) 페이지에 등록해 주세요.



BUZZ 고객센터

## 시리얼 번호 등록 안내

- 6개월 동안 품질보증 및 무상 A/S 제공을 위해 아래 안내에 따라 시간일 번호를 등록해주세요.

#### 시리얼 번호 등록 방법

- 1. 제품 앞면 아래쪽 또는 패키지 뒷면에 있는 시리얼 번호를 확인합니다.
- 2. 하단의 QR 코드를 통해 카카오톡 채널 "버즈 고객센터"에 접속합니다.
- 3. 시리얼 넘배를 입력합니다.









# 품질보증서

보 제품은 척처하 품직관리와 건나를 거쳐서 제조 스인되 제품입니다. 아래 기재된 내용으로 품질을 보증합니다.

레품명	Buzz Magmo Call Recorder	모델명	BUZZ-V7
구입일		보증기간	구입일로부터 6개월
고객		판매점	

### 제품 규격 (도표)

제품명	Buzz Magmo Call Recorder
모델명	BUZZ-V7
메모리	32GB (500 시간 녹음 가능)
최대 연속 녹음 시간	6시간
배터리 사용시간	6시간
배터리 충전시간	90분
크기	64,00mm × 95,80mm × 6,80mm
중량	44.2 g(1.56oz)
배터리	3.7 v Lithium-polymer 280mAh
사용 환경	온도 : 0 ~ 40도, 습도 : 20~40% (비용결)

#### Pre-Cautions Before Use

#### Consent and use of voice recording

- Depending on the user's country, city or state, if the call is recorded without the consent of both parties, the user may be subject to legal punishments according to the government issued law. Our company shall not be liable for any legal. punishments or actions.
- This device is compatible with the iPhone. We are not responsible for any damages caused while in use that is not provided in our guided instructions.

#### Additional information regards to consent in voice recording

- If the product is used on third-party conversations without any form of consent, the user may be subject to legal punishments according to the government issued laws. Our company shall not be liable for any legal punishment or actions,
- Distribution of other recordings (performances, lectures, music, etc.). aside from conversations, the user may be punished under the Copyright Act. Our company shall not be liable for any legal punishment or actions.

#### Read Before Usage

- Charge up to 1 hour before first usage.
- Use the USB cable provided when moving recorded data files, using other usb cables may not be able to move data.
- Before recording, make sure the switch is on. (slide upward diagonally)
- Refore charging, make sure switch is off, (slide down diagonally) Will not charge unless recording has been finished.

### **Product Composition**

# Product













☐ MagSafe Magnet ☐ Recording Button

# Start Call Recording

Slide the recording

button on the back of

you must attach a separate MagSafe magnet sticker to the back of the iPhone

A. If the product is recording while not fully attached to the phone the sound quality

The Please lower the button when you are not using it to prevent discharge of the product.

2) If the product is formatted to movable disc, it will not be able to play, copy or

3 Before disconnecting the device make sure to check 'Safe to remove hardware'.

① Make sure to slide the switch down diagonally before inserting to USB port for charging.

A. While it is recording, product cannot be charged. Make sure to slide the switch

A. While its charging the indicator light may alternate between red and green.



Product Instructions

1. Recordings: Start to End

the iPhone to connect the product UPWARDS

to attach the product.

2. Checking recorded data

delete recorded files.

3. Charging Duration: 90 minutes

down diagonally before charging.

but it means it has been fully charged.

of the recording will be low.

A Product can be used up to 6 hours straight.

Connect the device with USB cable to PC.

A. Device cannot record while it is connected to PC.

A. All recorded data (MP3) will be sorted in recorded order.

② Indicator light will display red once the device starts charging.

A. While the device is charging, it will not be able to record.

③ Once it's done charging, indicator light will display green.

to begin recording. (The Indicator light will turn blue for

A If you use a phone other than an iPhone with a built-in MagSafe.

0.5 seconds)



DOWNWARDS

when NOT in use

recording. The recording will save and then turn off, Keep the recording button

- Keep away from Childeren.

- Make sure to move recorded data to the PC in order to be saved,
- Damage caused by misuse of product will not be responsible by Our Company,

CS Center

- Related acquisition to Tech & Repair, please contact us through the online CS link https://bit.lv/3z37DN1
- Scan QR code displayed on the right to connect to "Customer
- Product can be replaced or fixed free of charge within
- 6 months of the purchase date.
- A. Warranty: Our Company will not warranty any product which has been subjected to improper usage, neglect or unauthorized
- In order to be serviced, make sure to have the serial number (placed at the bottom of the product or at the back of the
- placed on the right.

follow the following instructions.

#### 4. Battery Indicator

Battery % can be checked once the recording process have been completed through indicating light.

- A. While device is recording there won't be a light displayed.
- After it has been recorded, battery % will be displayed through indicator.

Indicator Light	RED	BLUE	GREEN	
Remaining Battery	(Low) 0~30%	(Medium) 30~70%	(High) 70~100%	


## 5. Product Reset

Device can be reset by connecting to the PC and reformatting. A. Deleted data can not be recovered.

- Do not place this device near heat, humid area, a dusty or an area with severe vibration.
- Do not purposely take apart or cause impact to the device.
- Do not submerge the device in water.
- If there is a problem with the device, Please contact Tech & Repair Service Support,
- Once the device's memory exceeds, it cannot record,

#### Tech & Repair Service

- Service Center for Magmo" link.



- repair or installation or exceeds the warranty period,
- product packaging) submitted through QR code (Customer Service Center for Magmo)

#### Serial number application

- In order for 6 months of quality assurance by Tech & Repair service, make sure to